

Gooseneck back-up mirror



The Gooseneck Back-Up Mirror mounts to your trailer.

Sight decals are placed on the truck bed. Using the rearview mirror, the Gooseneck Back-Up Mirror shows the sight decals and helps the driver align the trailer to the ball hitch.

Just look in your rear view mirror. Very Easy to Install





Align the Gooseneck Back-Up Mirror to the trucks rearview mirror.
Mark the drilling location.



Center punch the drilling locations



Drill holes using a 11/64" dia. drill. Drill 3/8" deep.
Note: It is okay to drill into the coupler.



Drive #10 self-tapping screws with washers. Use hand tools only!

Align the enclosed dot decals with leading edge of coupler & place on the truck bed.

View through back window



Here's a view through the rearview mirror.



Another view through the rearview mirror

